


# Mounting Kit for BlueWave® MX-Series Emitters Quick Start Instructions

This mounting kit (PN 60868) allows up to 2 BlueWave® MX-series emitters to be mounted directly to the side of a BlueWave® MX-Series Multichannel Controller. For BlueWave® MX 4-Channel Controllers, two mounting kits can be used simultaneously to mount all 4 emitters.



## Parts:

- 1. MX EMITTER MOUNT Qty 1
- 2. SCREW, M5 x 10 BHSCS (PN 41722) Qty 2
- WRENCH, HEX L, 3 MM, BAGGED (PN 40720) – Qty 1

Tools Needed: Safety Glasses

**IMPORTANT!** Safety glasses must be worn at all times during this assembly.

# **Assembly of Kit**

1. Line up the thumb screws on the mount with the mounting holes on the emitter (Figure 1). Tighten the thumb screws to fasten the emitter onto the MX emitter mount (Figure 2).

**Figure 1.** Line up Thumb Screws with Mounting Holes






Figure 2.
Mounted Emitter




2. Attach the mount to the controller - Using the supplied hex wrench, tighten the 2 screws through the mount and into the controller mounting holes.

**Figure 3.** Attach Mount to Controller




**Figure 4.** Controller with Mount Attached




3. To add a second emitter - Use the upper thumb screws to mount the second emitter as shown in Figure 5. Note: With a second kit, up to 4 emitters can be mounted (Figure 6).

**Figure 5.**Mounting Second Emitter

**Figure 6.**Controller with 2 Mounting Kits





## www.dymax.com

#### Americas

USA | +1.860.482.1010 | info@dymax.com

#### Europe

Germany | +49 611.962.7900 | info\_de@dymax.com | Ireland | +353 21.237.3016 | info\_ie@dymax.com

#### Asia

Singapore | +65.67522887 | info\_ap@dymax.com Shanghai | +86.21.37285759 | dymaxasia@dymax.com Shenzhen | +86.755.83485759 | dymaxasia@dymax.com Hong Kong | +852.2460.7038 | dymaxasia@dymax.com Korea | +82.31.608.3434 | info\_kr@dymax.com

#### ©2020 Dymax Corporation. All rights reserved. All trademarks in this guide, except where noted, are the property of, or used under license by, Dymax Corporation, U.S.A.

Technical data provided is of a general nature and is based on laboratory test conditions. Dymax does not warrant the data contained in this bulletin. Any warranty applicable to the product, its application and use, is strictly limited to that contained in Dymax's standard Conditions of Sale. Dymax does not assume responsibility for test or performance results obtained by users. It is the user's responsibility to determine the suitability for the product application and purposes and the suitability for use in the user's intended manufacturing apparatus and methods. The user should adopt such precautions and use guidelines as may be reasonably advisable or necessary for the protection of property and persons. Nothing in this bulletin shall act as a representation that the product use or application will not infringe a patent owned by someone other than Dymax or act as a grant of license under any Dymax Corporation Patent. Dymax recommends that each user adequately test its proposed use and application before actual repetitive use, using the data contained in this bulletin as a general guide.

QS099 9/08/2020