

Assembly Instructions for the ECE 5000 with Manual Shutter & ECE Light Shield

- Remove the Filler Plate from the bottom of the ECE 5000 Lamp (Figure 1). Look at the bottom plate of the ECE 5000 Lamp. Notice the cut-out in the Filler Plate.
- 2. Place the Glass Shield on the Lamp.
- 3. Place the Filler Plate over the Glass Shield with the cut-out face down. Check that the glass is sitting in this pocket.

NOTE: If the glass is not positioned correctly, there is the potential to crack the glass.

4. Secure the Glass Shield under the Filler Plate by installing the four screws (Figure 2). The screws should be hand tightened.

NOTE: Do not overtighten the screws. Doing so may cause the glass to crack.

- 5. Remove the Adapter Plate from the Manual Shutter by removing the four 8-32 x %" screws.
- Attach the Adapter Plate for the ECE 5000 to the Reflector Housing with M4 x 8 mm screws (Figure 3).
- Remove the four inner screws from the Light Shield's Top Plate (Figure 4).
- 8. Place the Manual Shutter on the Light Shield.



Figure 1. Lamp with Filler Plate Removed



Figure 2. Install Filler Plate




Figure 3. Install Adapter Plate to Lamp



Figure 4. Light Shield Top Plate, Remove Center M4 x 8 mm Screws



© 2013 Dymax Corporation. All rights reserved. All trademarks in this bulletin, except where noted, are the property of, or used under license by Dymax Corporation, U.S.A.

The data contained in this bulletin is of a general nature and is based on the property on the control data of the property of the contained in this bulletin. Any warranty applicable to products, its application and use is strictly limited to that contained in this bulletin. Any warranty applicable to products, its application and use is strictly limited to that contained in this bulletin. Any warranty applicable to products, its application and use is strictly limited to that contained in this bulletin. Any warranty applicable to products, its application and use is strictly limited to that contained in this bulletin. Any warranty applicable to products, its application and use is strictly limited to that contained in this bulletin. Any warranty applicable to products, its application and use is strictly limited to that contained in this bulletin. Any warranty applicable to products, its application and use is strictly limited to that contained in this bulletin. Any warranty applicable to products, its application and use is strictly limited to that contained in this bulletin. Any warranty applicable to products, its application and use is strictly limited to that contained in this bulletin. Any warrant the data contained in this bulletin. Any warranty applicable to products, its application and use is strictly limited to that contained in this bulletin. Any warranty applicable to products, the use is since the strictly for use in the user's interdeted manufacturing apparatus and methods. The user is should adopt such precautions and use a grant of license under any Dymax Europe GmbH recommends that each user adequately test its proposed use and application of the products before actual repretive use, using the data contained in this bulletin as a general guide.

Dymax Corporation 860.482.1010 info@dymax.com www.dymax.com Dymax Oligomers &Coatings 860.626.7006 oligomers&coatings@dymax.com www.dymax-oc.com

Dymax Europe GmbH +49 (0) 611.962.7900 info_de@dymax.com www.dymax.de Dymax UV Adhesives & Equipment (Shenzhen) Co Ltd +86.755.83485759 dymaxasia@dymax.com www.dymax.com.cn Dymax UV Adhesives & Equipment (Shanghai) Co Ltd +86.21.37285759 dymaxasia@dymax.com www.dymax.com.cn Dymax Asia (H.K.) Limited +852.2460.7038 dymaxasia@dymax.com www.dymax.com.cn Dymax Korea LLC 82.2.784.3434 info@dymax.kr www.dymax.co.kr

- 9. Attach the Reflector Housing/Shutter Plate Assembly to the Shutter and Light Shield with the Securing Brackets (Figure 5). Use M4 x 8 mm screws to attach the Light Shield to the Shutter and to secure the bottom portion of the brackets to the Light Shield's Top Plate.
- 10. Connect the Power Supply to the Lamp with the Interconnect Cable (PN 40695) (Figure 6).
- 11. Using a second Interconnect Cable (PN 40878), connect the ECE Light Shield to the J5 Receptacle on the rear panel of the Lamp.
- 12. Install the Bypass Connector in the J4 Receptacle on the rear panel of the Lamp.
- 13. Connect the Power Cable to the Power Supply and connect the opposite end to a power source. Unit is now ready to operate.





In addition to our light-curing equipment, Dymax also offers high-performance adhesives designed to rapidly bond glass, metal, and plastic substrates upon exposure to UV/Visible light and a variety of dispensing equipment. Our products are perfectly matched to work seamlessly with each other, providing design engineers with tools to dramatically improve manufacturing efficiency and reduce costs. Dymax is committed to providing the best chemistry, curing equipment, and dispensing systems that offer customers complete manufacturing solutions for their challenging applications.

S DYMAX

© 2013 Dymax Corporation. All rights reserved. All trademarks in this bulletin, except where noted, are the property of, or used under license by Dymax Corporation, U.S.A

The data contained in this bulletin is of a general nature and is based on laboratory tests conditions. Dynax Europe GmbH does not warrant the data contained in this bulletin. Any warranty applicable to products, its application and use is strictly limited to that contained in this bulletin. Any warranty applicable to products, its application and use is strictly limited to that contained in this bulletin. Any warranty applicable to products, its application and use is strictly limited to that contained in this bulletin. Any warranty applicable to products, its application and use is strictly limited to that contained in this bulletin. Any warranty applicable to products, its application and use is strictly limited to that contained in this bulletin as an even event solution and use is strictly limited to that contained in this bulletin. The user's interdeted manufacturing apparatus and methods. The user's sinterdeted manufacturing apparatus and methods. The user's sinterdeted manufacturing apparatus and methods are should adopt such precautions and use guidelines as may be reasonably advisable or necessary for the protection of property and persons. Nothing in this bulletin shall act as a representation that the product use or application will not infringe a patent. Dymax Europe GmbH recommends that each user adequately test its proposed use and application of the products before actual repatitive user, using the data contained in this bulletin as a general guide.

Dymax Corporation 860.482.1010 info@dymax.com www.dymax.com

Dymax Oligomers &Coatings 860.626.7006 oligomers&coatings@dymax.com www.dymax-oc.

Dymax Europe GmbH +49 (0) 611.962.7900 info_de@dymax.com www.dymax.de

Dymax UV Adhesives & Equipment (Shenzhen) Co Ltd +86.755.83485759 dymaxasia@dymax.com www.dymax.com.cn

Dymax UV Adhesives & Equipment (Shanghai) Co Ltd +86.21.37285759 dymaxasia@dymax.com www.dymax.com.cn

Dymax Asia (H.K.) Limited +852.2460.7038 dymaxasia@dymax.com www.dymax.com.cn

Dymax Korea LLC 82.2.784.3434 info@dymax.kr www.dymax.co.kr



Figure 5. Attach Securing Bracket with M4 x 8 mm screws



Figure 6. Rear Cable Connections